

# RAINsaver™


## EASY TO ASSEMBLE!

Fits standard 68mm round and 65mm square plastic downpipes.


**RAINsaver** is a simple to install product that allows you to collect rainwater from your downpipe without the water butt overflowing when full. The butt can either be positioned next to your downpipe or further away via an extended hose.

**A** Ensure lid is off water butt. If your water butt is not pre-drilled, then you will need to drill a 25mm hole to fit the Rainsaver.

**B** Drill points can be found in the top lip of the water butt to the left and right. Drill a 25mm hole on the side of the water butt closest to the downpipe centering the drill bit in the marked circular area. Push Rainsaver connector through the washer from the inside, then fit and tighten the nut on the outside to form a seal.



**C** Position water butt with tap facing forward adjacent to downpipe. If using a stand, place butt on it. A 30mm section now needs to be removed from the downpipe. Mark the downpipe 10mm below the top of the water butt. Mark again 30mm below this point. Using a hacksaw cut out this section.





**Remember**, if correctly fitted **RAINsaver** will always fill the butt to within 10mm of the top. Should a fitting error occur correct as follows: **Water butt overflows - raise butt**

**Water level too low - lower butt**

In the case of a low water level ensure enough rain has fallen to fill the butt before assuming a fitting error has occurred.

**D** Fit Rainsaver body with square end upright into the cut section of the downpipe.



**E** Connect hose between Rainsaver body and Water Butt connector.